
Subject: 6 Pin Footswitch for Kustom k250-4 Wiring
Posted by [burnthogan](#) on Tue, 02 Jun 2009 15:29:47 GMT
[View Forum Message](#) <> [Reply to Message](#)

I have a K250-4 & I am trying to get a footswitch working for it. does anyone have any schematics for builing the four button / six pin box or the Wah looking type boost pedal?

Has anyone built either of these? Can you point me in the right direction of some parts to do so.

Any info would be great. Please don't just respond with "check in previous posts" Been there.
