

---

Subject: Re: K200B-6

Posted by [steven](#) on Tue, 11 Feb 2020 13:58:01 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

3 ways to go about this without a Transistors matching / testing rig.

1) get a fist full of 2n3055 Transistors and install them one at a time while measuring and noting the D.C. Voltage on the speaker jack with no speaker hooked up .

The lowest D.C. Voltage seen will be a decent combination of matched Transistors.

The other way is to just buy 2 matched pairs of NTE130MP Transistors .

The 3rd way is that some folks offer a matching srvice that you can find online.

---