
Subject: Kustom

Posted by [jimbpilot](#) on Fri, 22 Jan 2016 16:55:50 GMT

[View Forum Message](#) <> [Reply to Message](#)

I have a couple of Kustom three tower JBL bass cabinets and I want to restore with JBL D-140 speakers. Does any body know the correct ohm speakers to use and the correct wiring ??
jimbpilot

Subject: Re: Kustom

Posted by [Kustom_Bart](#) on Fri, 22 Jan 2016 17:53:40 GMT

[View Forum Message](#) <> [Reply to Message](#)

You need three 16 ohm speakers for each cabinet. Wire them in Parallel and it will give you 5.33 total ohm load per cabinet.
