
Subject: Kustom 50-2 Reverb

Posted by [jammy5152](#) on Tue, 26 Apr 2022 10:56:10 GMT

[View Forum Message](#) <> [Reply to Message](#)

I bought a push/pull potentiometer off EBay and disassembled my broken Vib / Tremelo pot from my 50-2 amp and installed the parts from the new pot into the old pot body (the 3 solder terminals on the new one did not line up with the board holes) and re-soldered it back to the board...cleaned all pots and installed 3 prong cord...cut shaft of new pot (to long) ...installed temporary knob with screw until I find one that looks like Kustom knob(screw clamp knob)Works great...

Reverb seems to be not deep enough though... Any thoughts....Cleaned RCA JACKS....REVERB echos when amp is moved a little...
