Subject: Re: K150-6 pumps out DC voltage when powered on. Posted by corybrown on Sat, 14 Mar 2020 21:40:34 GMT

View Forum Message <> Reply to Message

Well got the new parts in. I replaced CR4 and CR5 and still the same behavior.

I have the replacements for Q5 and Q6 buy I'm curious about the heatsinks. Is there a way to remove the heatsink so it can be re-used?

Thanks