
Subject: Re: 250-4 original 4-switch footswitch markings?

Posted by [pleat](#) on Sun, 05 Jul 2009 18:10:18 GMT

[View Forum Message](#) <> [Reply to Message](#)

Peter, kustom offered a round footswitch with 4 switches that had a 4 pin XLR plug for the K200A series. I think that one would be labeled on a disc in the center of the switches.

The K250-4 footswitch had 4 pedals and a 5 pin XLR plug. To figure out which one is which, since you can't read the labels.

My schematic shows from left to right Trem/Vib, reverb, boost, and fuzz. These pedals used small light bulbs to illuminate the label, so maybe the bulbs are burned out or the pedal is not getting the voltage to run the lights. If you remove the back of the pedal the color coding would be, red + voltage, white wire is trem/vib, green is reverb, blue is boost, and orange is fuzz.

I can send you the schematic, shoot me an email at djt@chartermi.net

Don
