
Subject: Kasino Concert Guitar Head/ Model Con-L
Posted by [leejy](#) on Mon, 07 May 2018 00:53:32 GMT
[View Forum Message](#) <> [Reply to Message](#)

To all of you last geniuses of the analog era.

I have a Kasino Concert Guitar Head that I am trying to restore. The reverb is not working. The pan is OK everything is connected and I am able to hear the reverb output but the input is not being fed into the unit. The reverb works great if I feed it from an external device... Also the tremolo section is not working. All I get is a few db volume increase when I turn the depth potentiometer.

I got the feeling that a chip is dead or a capacitor...

Any suggestion?

The chip says 5558. Where can I find a replacement?

Any input would be greatly appreciated.

Thanks for reading
