Subject: Metal Film Replacement Resistors Posted by 77Pbass on Mon, 23 Feb 2009 03:37:07 GMT

View Forum Message <> Reply to Message

Anyone have a source for Metal Film Replacement Resistors that you like? I am tweaking a K200B-1 trying to eliminate noise.

Subject: Re: Metal Film Replacement Resistors

Posted by chicagobill on Mon, 23 Feb 2009 16:13:10 GMT

View Forum Message <> Reply to Message

First off, welcome to the board.

I get them from Mouser in Texas. They have a great selection and ship same day, so for me I get orders from them in 2-3 days.

I know in another thread that you are looking for schematics for your amp, I saw the pre-amps posted over at ampage. Try searching there. If I get a chance, I'll try to post a link.

Again, Welcome!

Bill

Subject: Re: Metal Film Replacement Resistors Posted by 77Pbass on Mon, 23 Feb 2009 16:27:11 GMT

View Forum Message <> Reply to Message

Thanks for the welcome and suggestion. I got the full schematics faxed to me by another member.

Regarding using MFR's, I see their tolerance is much tighter (1% vs. 10%). does this matter?

Subject: Re: Metal Film Replacement Resistors Posted by chicagobill on Mon, 23 Feb 2009 17:00:59 GMT

View Forum Message <> Reply to Message

No the tolerance does not matter as long as the basic value is correct. I would suggest starting with the pre-amp boards and then do the power amp board.

I was surprised at the difference that changing a few resistors and a few caps made in terms of the background noise and hiss levels. Even though you will notice a difference don't expect the amp to be dead silent.

For anyone that needs the schematics for the PC105 pre-amp board or the PC703 power amp board here's the link.

Subject: Re: Metal Film Replacement Resistors

Posted by 77Pbass on Mon, 23 Feb 2009 18:39:33 GMT

View Forum Message <> Reply to Message

yeah...that's exactly what I am going to do after reading copius amounts of posts by those who have gone before me.

I don't expect total silence but I believe I can reduce the waterfall to a trickling creek.

Thanks for the link to the schematics. I found others on that board but had Boost instead of Bright...those PDF's are good as the values are very clear.

I was reading elsewhere that you can upgrade the Output Caps and Bridge Rectifier(?) to get more headroom and possibly volume. I may tackle that after tweaking the pre-amp.

Subject: Re: Metal Film Replacement Resistors

Posted by C4ster on Mon, 23 Feb 2009 18:49:05 GMT

View Forum Message <> Reply to Message

Just make sure the voltage rating is the same or higher. I generally install caps that are 2 to 4 times larger. For a 2500uF I would put in 10,000uF. Typically in K100's. Or for 4700uF I would use 15,000 to 20,000uF. You might change the AGC3 fuse to a slow blow fuse. I generally don't change the bridge. That brige is very beefy as it is. But a 200VDC 25Amp bridge should be large enough.

Conrad

Subject: Re: Metal Film Replacement Resistors

Posted by chicagobill on Mon, 23 Feb 2009 20:44:24 GMT

View Forum Message <> Reply to Message

Changing out the filter caps and upgrading the bridge rectifier will help to get the most usable sound out of the amp, but it will not get more power from the amp.

Subject: Re: Metal Film Replacement Resistors

Posted by stevem on Tue, 24 Feb 2009 11:15:21 GMT

View Forum Message <> Reply to Message

Making a bridge out of fast recovery diodes(freds) will take some switching hash (noise) out of the amps idle noise floor that is mistaken for hiss.

Subject: Re: Metal Film Replacement Resistors

Posted by 77Pbass on Tue, 24 Feb 2009 15:12:44 GMT

View Forum Message <> Reply to Message

Which part number on the PC703 Schematic is the Bridge Rectifier? CR702?

Subject: Re: Metal Film Replacement Resistors

Posted by chicagobill on Tue, 24 Feb 2009 16:52:07 GMT

View Forum Message <> Reply to Message

No, it isn't shown on the PC702 drawing. It appears on the overview page that shows the pre-amp boards and the power supply. It is listed as CR1.

On your amp, it is bolted to the floor of the chassis. It is 1 1/2" - 2" round (at least if it is the original one) and has 4 terminals with 2 wires that come from the power transformer and a red (+) and green (-) wire that go to the large filter caps.

Subject: Re: Metal Film Replacement Resistors

Posted by 77Pbass on Wed, 25 Feb 2009 15:15:46 GMT

View Forum Message <> Reply to Message

Thanks Bill. I only have the PC board schematics. The amp is all original...I spent an hour cleaning 1970 grime from the chassis.

The part you refer to is clearly visble in this photo:

http://picasaweb.google.com/77Pbass/KustomK200B102#530503703 4957960066

Subject: Re: Metal Film Replacement Resistors

Posted by stevem on Wed, 25 Feb 2009 17:06:17 GMT

View Forum Message <> Reply to Message

Yes, the round item with the four wires coming off it is the bridge rectifier.

They do not make FRED type as a bridge, so you will have to make it up from 4 seperate ones on a terminal strip or bread board.

I will fax you a schematic of the power supply with the preamp, but I tryed to fax the preamp one to you yesterday and that fax number did not work, so please check it for me.

Subject: Re: Metal Film Replacement Resistors

Posted by 77Pbass on Fri, 27 Feb 2009 14:12:17 GMT

View Forum Message <> Reply to Message

I'll have to get some information on creating the bridge rectifier from 4 seperate FRED's later

Subject: Re: Metal Film Replacement Resistors Posted by pleat on Sat, 14 Mar 2009 02:51:43 GMT

View Forum Message <> Reply to Message

If it's any help, I have a bridge rectifier from a Kustom 3 monitor amp circa 1975 era. It is a little smaller in size but has the 4 tabs on it for hooking up the leads. 20.00 I looked on the schematic and it shows the power amp using 40.2 volts and I know the older K200 series shows 39.5 volts. Not sure if there would be a problem or if there is something else in the amps that regulates the proper voltage. The Monitor is a donor amp, Tranny is now in my K150 2x10 amp and the power amp board and transistors found a home in NC. pleat