

---

Subject: Ports History

Posted by [oren hudson](#) on Wed, 09 May 2018 03:31:02 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I recall reading somewhere the general info on when the ports were added to the cabs. My brain has failed on remembering that info and I don't seem to find it in a search, so here goes. When did the ports first start? Was there a difference between guitar cabs and bass cabs as to whether or not the ports were installed? I ask because I've looked at a (terrible) pic of what the owner says is a gold covered cab. He knows nothing else about it. Appears to be gold or possible silver 2x12 or 2x15 with the ...by Ross emblem and no ports. Any clues? Thanks.

---

---

Subject: Re: Ports History

Posted by [chicagobill](#) on Wed, 09 May 2018 04:15:58 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

From what I remember, all cabinets after a certain point had ports cut into the baffle board, but not all cabinets had the front mounted aluminum or chrome port bezels.

I have an early horizontal 2X15 cab that has no ports. All of the vertical cabinets that I have seen have ports. Pleat will have a better answer for you, I'm sure.

---

---

Subject: Re: Ports History

Posted by [steven](#) on Wed, 09 May 2018 10:07:12 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Lol! And I have a early horizontal 2-15 white cab with the baffle holes !

---

---

Subject: Re: Ports History

Posted by [pleat](#) on Wed, 09 May 2018 10:59:05 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

The early Frankie cabinets were offered in a 2x15 side by side, and then went to a vertical 2x15 and 3x15 cabinets. Most early cabinets have portholes behind the grill cloth and some don't. Bud said in the early years he was cutting the holes by hand and broke his saw, he said he didn't have the money to replace the saw, so he concentrated on just cutting the holes for the 15" speakers. Looking at the side of the cabinets, they had a slight taper narrower at the top and wider at the bottom. The K200 A cabinets were 12 T&R wide and had 3" ports behind the grill cloth, or as a 20.00 up charge, you could get the 4" aluminum ports. Name badge would say Kustom by Ross Inc. Sometime in 68 Kustom started building all the cabinets with the port tubes as standard. The 69/73 cabinets changed to chrome plastic ports and the name badge said Kustom Electronics Inc. pleat

---

---

Subject: Re: Ports History

Posted by [kustomoholic](#) on Thu, 10 May 2018 15:50:23 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

My blue 2-15 vertical Frankie cab has no ports. (11 pleats) I stuffed it full of insulation to make the cab feel bigger. I used it with the Blue Frankie head and it sounds decent with the 2 15" Eminence drivers I salvaged from a La15 and what was in my Charger that I swapped in an Altec421a-8h. I used that Frankie rig in Indy in 2011.

---

---

Subject: Re: Ports History

Posted by [BrianBB](#) on Fri, 18 May 2018 01:12:02 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I have a charcoal vertical 2x15 Frankie head and cabinet. No ports cut in the baffle.

---

---

Subject: Re: Ports History

Posted by [steven](#) on Fri, 18 May 2018 09:57:07 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

It would be great to have the manufacture date off of the speakers, then we may be able to start a data base and pin down when the change over was to baffles with holes.

---

---

Subject: Re: Ports History

Posted by [oren hudson](#) on Sat, 19 May 2018 03:19:00 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I opened the cab up and found that they were obviously CTS square magnet speakers, but sadly, no numbers anywhere on the speaker frames. Other notable items: slotted screws used on the back panel, no sealer (turned to tar) used on the back panel and a blank speaker jack plate. It sounded amazing when I cranked it for a while with an SVT head!

---

---

Subject: Re: Ports History

Posted by [steven](#) on Sat, 19 May 2018 10:14:12 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Most CTS date codes are on the magnet.

---

---

Subject: Re: Ports History

Posted by [oren hudson](#) on Mon, 21 May 2018 01:27:57 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Success! I got the cab out in the bright sunshine Sunday and took the back panel off. I looked and looked and looked at the speakers for the code. Nothing. I then got a large magnifying glass out and a super bright blind your eyes flashlight and scoured the magnet at all angles for any possible trace of the numbers. I did manage to find a very faint number with a hint of green that CTS typically used. After detailed examination, made out the prefix to be 137. Then the big mystery date numbers - date code is 638. So, looks like a mid '66.

---

---

Subject: Re: Ports History

Posted by [MrShake](#) on Mon, 11 Jul 2022 14:45:20 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I know I'm digging up an old thread, but I've been playing through my K200B-1 and non matching 2x15 (acquired separately) for the past year and have been consistently impressed with it. The head is a 1969 that had a hard life before I got it.

My cab is a black, tapered, 11-pleat cab, so, from the Frankie era. No sealant, blank jack plate, no front logo, no ports.

I got it on clearance at Empire Guitars in Providence, RI, where they apparently used to have a huge Kustom collection. It was the last one, at \$160. I've been playing it in Boston ever since.

Unfortunately, my speakers are a pair of 1970 CTS. They sound great, but I'm assuming between 1965-1969, someone blew the originals. Everything else is in top condition, barely a scuff, so I assume it wasn't a smashed baffle or anything.

Sorry I can't add more to the historical record with original speaker date codes, but wanted to leave a record of the cab in this thread for posterity. Thanks to everyone for sharing their information.

---

---

Subject: Re: Ports History

Posted by [stevem](#) on Mon, 11 Jul 2022 15:39:33 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Thanks for posting the info that you have!

What is the impeadence of those drivers ?

The originals where 16 ohm which when wired in the way the factory did made for a 8 ohm load on the amp.

This then limited the amps output to some 50 watts of clean power instead of 100 wats with two 8 ohm speakers and a 4 ohm load like the amp was really designed for.

---

Subject: Re: Ports History

Posted by [MrShake](#) on Mon, 11 Jul 2022 16:50:07 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

You're quite welcome. The drivers are 16ohms, wired for 8ohms total. I'm excited to finally take it to the practice space this weekend and plug in a second 1x15 8ohm cab and let it rip at full capacity of 4ohms. Thanks for the tip!

I forgot to mention, mine also has the original handles replaced with the later chrome/plastic ones, but you can still see the holes for the original handles in the vinyl. I feel like this supports my theory of a factory replacement of the speakers around 1970, where they swapped for new handles to replace the originals which I imagine were broken.

And for what it's worth, my cab also has slotted screws.

---

---

Subject: Re: Ports History

Posted by [MrShake](#) on Tue, 26 Jul 2022 12:47:58 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I was mistaken, mine does not have flathead screws:

---